

XP600 LARGE FORMART PRINTER DEFAULT SETTINGS

ADVANCED SET UP

Access to advanced set-up is gained by simultaneously pressing all 4 arrows on the Printer (up, down, left, right)

Below are the default settings

1. **Print width:**155cm
2. **Raster type:** B
3. **Carriage type:** DC
4. **Paper motor:** Step
5. **Wiper direction:** Normal
6. **Wiper Directional:** Normal
7. **Paper directional:** Normal
8. **Carriage direction:** Reverse
9. **Acc distance:** 60mm
10. **Paper speed:** 50
11. **LCD type:** B
12. **UV Type :** D
13. **Auto clean:** Split
14. **Wiper speed:** 68
15. **Station speed:** 84
16. **Main CFG:** Entry
17. **24 V Mode:** Heat

.....